
PALMA - PALMA - MAS

Operation Instructions

SAVE THESE INSTRUCTIONS



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

CONTENTS

Safety and maintenance	02
Name and function of components	04
Function	05
Method of usage	06
Product specification	15

Safety and maintenance

1.Important Safety Warning.



- Don't allow children to touch moveable part of this product.
- Please use well-grounding power supply suited to this product.
- Please pull out the plug after use or before cleaning to avoid injury or Damage to the product.
- Please operate this product according to this manual instruction.
- Don't use accessories which are not recommended.
- Don't use this product outdoors.
- · Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- 20 minutes of usage each time is recommended.
- Please don't use it if the leather is broken or damaged.
- Please don't use it if the cover or leather is damaged.
- Please don't use it if the radiator hole is covered or blocked.
- · Please don't drop anything into this product.
- · Please don't fall asleep while using this product.
- · Please don't use it if drunk or feel unwell
- Please don't use it within one hour after having meal.
- Please don't make the massage function too strong for avoiding Injury.

2. Environment for usage.

- Please don't use it under high temperature and moist environment such as bathroom.
- Please don't use it immediately while the environmental temperature changes sharply.
- Please don't use it under heavy-dusty or caustic environment.
- Please don't use it where there is not enough space or not good ventilation.

3. People who are not suitable to use this product.

- People who are suffering from osteoporosis are not suitable to use this product.
- People who are suffering from heart disease or carrying electronic medical equipment such as heart pacemaker are not suitable to use this product.
- People who are suffering from fever are not suitable to use this product.
- Pregnant women or women that are in menses period are not suitable to use this product.
- People who got injured or skin disease are not suitable to use this product.
- Children under 14-year old or people mentally unbalanced without being Supervised are not allowed to use this machine.
- People who are told by doctor to have rest or people who feel unwell are not suitable to use this product.
- People whose bodies are wet are forbidden to use this product.
- The appliance has a heated surface persons insensitive to Heat must be careful when using the appliance.

4. Safety.

- Check the voltage if it is suitable to the specification of this product.
- Don't use wet hand to pull the plug.
- Don't make water go inside this product to avoid electric shock or cause damage to this product.

Safety and maintenance

- Don't damage the wires or change the circuit of this product.
- Don't use wet cloth to clean the electric parts such as switch and plug.
- Be away from this product under power cut state to avoid injury if the power comeback suddenly.
- Stop using this product while it works abnormal, and please consult local agent immediately.
- Stop using this product if you feel unwell, and please consult health care doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Service agent or similarly qualified persons in order to avoid a hazard.


5. Maintenance.

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses.
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a Hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.
- · Don't use edged res to thrust this product.
- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for long.

6. Solution of ordinary malfunctions.

- It is nature movement voice if the motor sounds while in usage.
- If the controller can't work normally, please check the plug and socket if they are connected strongly and make sure the switch is turned on.
- If the rated working time is over, the product will automatically activate the poweroff button; If this product works continuously for long, the temperature protector will make the product automatically power-off, it should be used again after half an hour's rest.


Name and function of components



Function

- This product is designed with a set of four- wheel driven mechanical massage hands that can move up and down while stretching back and forth.
- Designed with five types emulation massage methods of shiatsu, kneading, tapping, knocking, simultaneous kneading and tapping.
- The shoulder part of the product is designed with an automatic detection and micro adjustment function
- Set with six kinds of characterized auto massage function: ache relieve, comfort, ease, demo, upper body, lower body
- This product is set with 2 memory functions: M1 and M2.
- Manual massage for the upper body with five options: overall, partial area, fixed spot, upper back partial area and lower back partial area massage. With five types emulation massage methods of shiatsu, kneading, tapping, knocking, simultaneous kneading and tapping. Each massage method with three grades of speed adjustable. In state of fixed spot and partial area, the massage hands can move up and down to adjust the massage point accurately. In the state of tapping, shiatsu and knocking, the width between the two kneading balls is adjustable with three grades: wide, medium and narrow.
- Air pressure massage function: full body air pressure massage, arms air pressure massage, (the upper arms are built with 4 air bags and the arms are built with 8 air bags), legs air pressure massage (with 16 air bags), with 3 modes and 3 intensity levels optional.
- Legs designed with roller massage function. At the bottom of foot, two pairs of mastoid rotating massage on toe root; scraping massage on the arch and heel.
- The back heating function uses carbon fiber as an infrared heating source
- The footrest can be extended to suit different leg lengths
- As the back rest reclines down, this product is built to save wall space by making the chair slide forward.
- The calf rest and back rest can be adjusted, and auto lay down mode to better suit the user's preferences.
- L shape back track fitting your body curves, can realize the zero gravity when
- The audio speakers are located on the upper arm area of the product, music can be played by connecting the blue tooth to a smart phone or tablet device.
- Negative oxygen ions generator set on the upper armrest.
- Design with LED light on each side of the armrest.
- With fast button on right armrest, including switch on/off, zero gravity, auto, linkage move.
- · Design with USB charger on right armrest.
- Head Cusion design with two sections and collapsible design (2 levels when folded), customer can use different levels up to their needs. To reduce the massage intensity of neck area. When extend to back area, can reduce the massage intensity of back area. Offer different choices to customer.

Note: The specific displays refer to the actual object of this product!



Method of usage


1.Switch power supply on



2.Start to massage

- 1). Press power button, massage chair automatically reclining, and start massage.
- Automatic shoulder position and massage acupressure point detection, waiting for the completion of testing.
- 3). If there is difference with the massage balls and the actual shoulder position, youcan adjust the up and down button to a suitable position. Shoulder position has 10 grades adjustable. It will run automatic massage if there is no adjustment on shoulder position within 10 seconds

Button	Description	Display
Adjust	Move the massage balls upward to a suitable position	
Adjust shoulder	Move the massage balls downward to a suitable position	



- 4) Choose massage function to massage
- Memory function massage
 Press button "Upper body / M1" or "Lower body /M2" for 3 seconds, then enter into memory massage function "M1" or "M2", it will revert to the previous memory massage mode.

Function	Button	Display
Memory Massage	Que de la companya della companya della companya de la companya della companya de	Memory
	Powe, we	Memory

Characterized auto massage

Function	Button	Feature	Display
	Ache relieve	Deeply massage on acupressure points, effectively alleviate pain	Auto F1
Ob and the land	Comfort NAI	Loosen body physique	Auto F2
Characterized auto massage	Oemo Relax	Promote blood circulation	
assags	Relax	Fast to experience all the massage effect (press for 2s, switch to speed press)	Auto F0
	Upper body/M1	Massage focus on upper body	Auto F4
	Lower body/se2	Massage focus on lower body	Auto F5

• Upper body manual massage

Function	Button	Adjust Massage Ball	Display
	Shiatsu	Speed And Width	
	Knead&flap	Speed	
Technique	Flap	Speed And Width	
	Knead	Speed	
	Knock	Speed And Width	
Speed Speed Width Width		Three Grades Speed Adjustable	Speed
		Three Grades Widths Adjustable	Width

Method of usage

Function	Button	Description		Display
	Back Stretch	Fixed position (fixed spot) massag	е	[-] но
	Back Stretch	Small area (partial area) massage	back and forth	尚 H1
	Overall massage back and forth		(Ĵ H2	
	Back Stretch	Jpper back massage back and forth		[] нз
Back	Back Stretch	Lower back massage back and forth		∫) _{H4}
Stretch	Massage point adjust (in fixed	Massage hand move up		
	•	spot, partial modes you can adjust the massage position)	Massage hand move down	

Air pressure function massage

· ··· p·······················g··			
Function	Button	Description	Display
Air pressure mode	Air pressure	Three air pressure modes (full body, arms and legs) for lower body	Arm
Intensity	Air Intensity	With three grades adjustable	Arm IIIIIIIII Feet IIIIIIIII

Other manual function

Function	Button	Description	Display
Roller	Roller Sole roller: sole roller switch, with 3 speed levels available		1
Heating Far infrared back heating, has warm fit start to work 3 minutes later		Far infrared back heating, has warm feeling when it start to work 3 minutes later	Ž
Negative oxygen ions function Long press for 3 seconds to on/off negative oxygen ions function		00	

• Other manual function

Function	Button	Description
Calf rise	D	Calf rest lifting button, press this button, calf restlifting slowly, stop when release it
and dron		Calf rest decline button, press this button, calf rest decline slowly, stop when release it
Backrest rise	•	Backrest lifting button, press this button, backrest lifting slowly stop when release it
and drop	•	Backrest decline button, press this button, backrest decline slowly, stop when release it
Auto lay down mode	ZERO	With three modes circulation function, when press the button, turn into auto lay do wnmode.

· Arm rest fast button

Function	Button	Description
On/off	Ф	Press this button switch on or off the chair
Linkage move up	بخ	Press and hold this button to slowly lift the backrest and lower the leg rest. Release the button to stop
Zero gravity	≈ Zero	Press one time, switch one auto lay down mode, total 3 modes circulation
		Press and hold this button to slowly lower the backrest and lift the leg rest. Release the button to stop
Auto modes	AUTO	Press one time, switch one auto massage functionUSB
USB		USB charger. Can charge your smart device (cell phone)

3. Turn off power, stop massage

- 1) Press power button during massage progress, all massage function will be stop immediately, the backrest and footrest will return to original position automatically, meanwhile you can set up memory function. After rated working time, all massage functions will be finished, meanwhile you can set up memory function, but backrest and footrest won't return to original position.
- 2) Memory store function: After rated working time or switch off, the hand controller displays "Memory" and glitter, remind the users whether need to store the massage mode before turn off, you can press the memory function buttons "M1" or "M2" as you like, store the massage mode.
- 3) Cut off the power of the whole machine. Figure (Switch power off)








Unplug the power cord

Method of usage

4. Installing the Arm Rests

- Find out the coupler plug from the seat frame base respond to the arm rest, go through out the end mid of the seat frame (Figure 1)
- After you finish the step 1, connect each plug according to the remarks on the wire. (Figure 2)







Figure 1

Figure 2

- Insert the plug well which go out from the seat frame base, as well as the air hose. (Figure 3)
- After you insert the plug well, put the wires in to the seat frame base along with the metal tube, then put on the cloth cover, avoid to the air hose folded. (Figure







Figure 3

Figure 4

- Hold the armrest front and rear part, make the armrest rear part close to the lower part of the capsule. (Figure 5)
- Insert the lower limited axle on the rear part of the armrest to the lower limited block on the capsule, (Figure 6)






Figure 5

Figure 6

- After the rear part finish, make the front part of the armrest close to the metal tube, and insert the hook on the armrest front part to the seat frame metal tube. (Figure 7)
- Press the armrest downward until it in the right position, then push the front part of the armrest upward, make the hook which on the armrest front part close to the metal tube, swing the armrest gently, check the armrest is it installed well. (Figure 8)







Figure 7

Figure 8

- Unzip the PU cover on the upper arm, across the cross screw from the capsule screw hole with a cross screw driver, and make the capsule and armrest fixed well, then zip up the upper arm PU cover. (Figure 9)
- Align the hole on the metal tube which on the front part of the armrest, tighten the cross screw on the armrest frame with a cross screw driver, finish the installation, and the same steps for the two armrests. (Figure 10)








Figure 9

Figure 10

5.Calf installation


- Install the rotating shaft in calf fixed axis first, noticed the hole should be aligned, so that the R shape pin assembly (Figure 1)
- After calf is connected with the fixed axis aligned, then insert (Figure 2)





Method of usage

- Plug R pin, then moved to the other side of the calf, and plug R pin (Figure 3)
- Finished (Figure 4)







Figure 3

Figure 4

Note

- When the chair is working under the lay down mode and the calf rest is lifting, you can't press on the calf rest, avoid to the chair fall forward to cause injury.
- Please check the massage hand is it in the seat position when you sit down, avoid to uncomfortable feeling on your gluteus when you sit in because of the human body weight.







Figure 1


Figure 2

6. Head cushions and backrest pad's dismounting and use manual

 Using head cushions can reduce the kneading massage intensity on neck and shoulder, according to your needs to decide whether the head cushions is needed (recommend head cushions). Backrest cushion and backrest connected by zipper (1), head cushions and backrest pad connected by thread gluing (2).








12

8.Floor Protection


• Put the heavy massage chairs on the wood floor for a may damage the floor, so please place a carpet or other object to avoid this damage.



Caution: Do not move the chairs with its wheels on wood floor, rough ground or in a narrow space. Two people are required to lift the chair. During the lifting period, take the calf rest end sealing plate and backrest cover grooves as the force-bearing point(Please do not lift armrest directly.)

9.Method of movement

 Make sure that all wires are far above the ground, tilt the backrest backward to a certain degree (with the gravity center resting on the wheels), push the chair forward or backward with your hands and finally resume the chair to the normal position in a slow and gentle manner.



Note: During movement you must turn off the power first and then unplug the power cord and the controller cord.

14

Product specification

Model: Palma

Name: Massage Chair

Rated voltage: 110-120V~ 60Hz

220-240V~ 50Hz/60Hz .

Rated power input:150W Rated time: 20Min Safety structure: Class I

Material introduction: PVC, PA, steel parts and electric &ele

-ctron parts

MATERIAL	PU	LEATHER	CLOTH	WOOD

15