


# A33 FULL BODY AIR-MASSAGE CHAIR OPERATION INSTRUCTIONS

SAVE THESE INSTRUCTIONS



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use. Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

# **CONTENTS**

Safety and maintenance	02
Name and function of components	04
Function & Efficacy	05
Method of usage	16
Product specification	16

# Safety and maintenance

# 1.IMPORTANT SAFETY WARNING.

- Don't allow children to touch moveable part of this product.
- Please use well-grounding power supply suited to this product.
- Please pull out the plug after use or before cleaning to avoid injury or Damage to the product.
- Please operate this product according to this manual instruction.
- Don't use accessories which are not recommended.
- Don't use this product outdoors.
- Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- 20 minutes of usage each time is recommended.
- Please don't use it if the leather is broken or damaged.
- Please don't use it if the cover or leather is damaged.
- Please don't use it if the radiator hole is covered or blocked.
- Please don't drop anything into this product.
- Please don't fall asleep while using this product.
- Please don't use it if drunk or feel unwell.
- Please don't use it within one hour after having meal.
- Please don't make the massage function too strong for avoiding Injury.

### 2. Environment for usage.

- Please don't use it under high temperature and moist environment such as bathroom.
- Please don't use it immediately while the environmental temperature changes sharply.
- Please don't use it under heavy-dusty or caustic environment.
- Please don't use it where there is not enough space or not good ventilation.

### 3. People who are not suitable to use this product.

- People who are suffering from osteoporosis are not suitable to use this product.
- People who are suffering from heart disease or carrying electronic medical equipment such as heart pacemaker are not suitable to use this product.
- People who are suffering from fever are not suitable to use this product.
- Pregnant women or women that are in menses period are not suitable to use this product.
- People who got injured or skin disease are not suitable to use this product.
- Children under 14-year old or people mentally unbalanced without being Supervised are not allowed to use this machine.
- People who are told by doctor to have rest or people who feel unwell are not suitable to use this product.
- People whose bodies are wet are forbidden to use this product.
- The appliance has a heated surface persons insensitive to Heat must be careful when using the appliance.

# Safety and maintenance

### 4. Safety.

- Check the voltage if it is suitable to the specification of this product.
- Don't use wet hand to pull the plug.
- Don't make water go inside this product to avoid electric shock or cause damage to this product.
- Don't damage the wires or change the circuit of this product.
- Don't use wet cloth to clean the electric parts such as switch and plug.
- Be away from this product under power cut state to avoid injury if the power comeback suddenly.
- Stop using this product while it works abnormal, and please consult local agent immediately.
- Stop using this product if you feel unwell, and please consult health care doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Service agent or similarly qualified persons in order to avoid a hazard.


### 5. Maintenance.

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a Hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.
- Don't use edged res to thrust this product.
- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for long.

### 6. Solution of ordinary malfunctions.

- It is nature movement voice if the motor sounds while in usage.
- If the controller can't work normally, please check the plug and socket if they are connected strongly and make sure the switch is turned on.
- If the rated working time is over, the product will automatically activate the power-off button; If this product works continuously for long, the temperature protector will make the product automatically power-off, it should be used again after half an hour's rest.

# Name and function of components



- 1.Pillow pad
- 2.Controller
- 3.Arm air bag components
- 4.Seat cushion
- 5.Leg rest frame
- 6.Foot rest frame
- 7.backrest pad
- 8.Armrest
- 9.remote controller pocket
- 10.backrest cover
- 11.Controller support
- 12.MP3 Player Box
- 13. Moving wheels
- 14. Power cord and plua
- 15.Earphone socket
- 16.power plug socket
- 17.Power switch
- 18.Fuse box

# Function & Efficacy

### **Function**

- This product is designed with a set of smart 3D mechanical hands, which can move up and down, stretching back and forth, four-wheel driven with muted design.
- 2. The shoulder part is designed with automatic detection and micro adjustment function; body curve and massage points automatic detection, it can automatically adjust the distance of massage hands' moving back and forth according to the detected body curve and massage points, to make the massage more humanistic and scientific.
- 3. Designed with automatic massage programs
- Air pressure, waist twist, swing hip, waist stretch and other specific massage functions.
- 5. Manually select the upper body massage; three massage position options of overall, partial and fixed position; six massage methods of shoulder grasping, kneading, tapping, shiatsu, kneading&flapping and 3D; five massage speed levels available; under tapping and shiatsu massage status, the width of the massage hand can be adjusted in five levels.
- 6. Arm air massage function (built-in 26 airbags), leg air massage function (built-in 38 airbags), with 3 intensity adjustments
- 7. Upper-body air massage: neck and shoulder air massage function (built-in 8 airbags), seat air massage function (built-in 16 airbags)
- 8. MP3 music displayer. pause, previous, next, volume up, volume down.
- 9. Back heating function. Use carbon fiber as infrared heating source
- 10. The footrest can be extended to suit various heights.
- 11. Footrest lifting and backrest lift adjustment
- Auto-sitting function, massage Massage hands can automatically return to Original position after turning off.
- 13. VFD display
- 14. MP3 player, earphones, U disc

### **Effectiveness**

Release fatique


Accelerate blood circulation

Release muscle fatique

Release muscle tension


Release nerve pain

Release the muscle pain.



# 88Min 88 Auto Arm Will Shoulder Back Width Will Memory set on





# Method of usage

# 1. Switch power supply on




# 2.Adjust angle of backrest and footrest

Footrest up button: press this button and the footrest will recline slowly, release the button it will stop.	<ul><li> ▼</li></ul>
Footrest down button: press this button and the footrest will decline slowly, release the button it will stop.	
Backrest up button: press this button the backrest will recline slowly. release the button it will stop.	<ul><li> ▼</li></ul>
Backrest down button: press this button the backrest will decline slowly. release the button it will stop.	
Position adjust up button: press this button the backrest will recline and the footrest will decline slowly. release the button it will stop.	
Position adjust down button: press this button the backrest will decline and the footrest will recline. release the button it will stop.	

### 3. Start massage

- 1). Press the red power button to start massage, the massage chair will recline automatically.
- 2). Automatically detecting shoulder position and massage points, please wait till dection finished.
- 3). It sounds [di di di...] after detection finished. Now, please adjust the shoulder position by pressing up or down button. It will run automatic massage if there is no adjustment on shoulder position within 10 seconds.

Move the massage balls upward to a suitable position.	ADJUST SHOULDER	
Move the massage balls downward to a suitable position.	ADJUST SHOULDER	



### 4) . Choose massage methods

### · Automatic massage

Relax: relax muscles and bones	AUTO	Auto F1
Ease: accelerate blood circulation	AUTO	Auto F 2
Ache Release: make deep massage to relax the ache position	AUTO	Auto F 3
Fatigue recover: release the fatigue and activate body	AUTO	Auto F 4

08

Note: Press the buttons repeatedly and choose different automatic massage methods, the four automatic massage methods can run circularly.

# Method of usage

### · Specific massage

Whole-body air massage: air massage on neck&shoulder, waist, buttock, arms and thigh positions will work at the same time.	UPPER BODY		Auto F5
Waist twist: focus on waist massage, the waist airbags make waist twist leftside and rightside, meantime the seat airbags make hip-swing massage	WAIST TWIST	S	Auto F6
Swing Hip:focus on hip massage, swing hip machanism and seat cushion pressure operating makes hip swing left and right	SWING HIP	\$	Auto <b>F7</b>
Waist stretch: When the calf airbags work and squeeze calf part, the backrest lays down and calfrest pulls down to stretch the waist part, then return to original position and repeat above actions. Meantime the seat airbags and massage mechanism works.	WAIST STRETCH		Auto F8

### · Upper-body manual massage

Shoulder grasp: 1 method available with speed and strength adjustment	© &	( H1 )
Shiatsu: 2 methods available with speed, width and strength adjustment.		(H1~H2)
Kneading: 2 methods available with speed strength adjustment.	<i>S</i>	(H1∼H2)
Flapping: 2 methods available with speed, width and strength adjustment.		<b>(</b> H1∼H2)
Kneading&Flapping: 2 methods available with speed strength adjustment.	<i>⋑</i>	(H1~H2)
3D: 4 methods available with speed and strength adjustment.	3D	3D (H1∼H4)
Speed: 5 leves available	SPEED	Speed mm
Width: 5 levels available (only underflapping and shiatsu status).	WIDTH	Width www.

Backrest stretch (can be operated under all manual modes except shoulder grasp status).				
Fixed massage		BACK STRETCH	[.]	
Partial massage		BACK STRETCH		
Overall massage		BACK STRETCH		
Position adjustment (under fixed and partial	Massage mechanism up	•		
status, the position can be adjusted).	Massage mechanism down	<b>(A)</b>		

### · Lower-body manual air massage

Foot: foot air massage with 3 strength available When foot air massage is working, the footrest stretch function will run automatically	CALF	Feet www.
Upper-body: neck&shoulder, waist and seat air massage	UPPER BODY	Shoulder Back Buttocks
Arm: arm air massage with 3 strength available	ARM	Arm www.

Note: Under automatic massage status, it can adjust the relative air massage strength by pressing any button of Arm, Upper-body and Foot

### · Other manual functions:

Foot roller: with 3 speed levels available	SOLE ROLLER	
Backrest heating: backrest infrared heating massage, can be felt after 3 minutes	BACK WARMER	Ä

10

# Method of usage

Upper-body strength adjustment with 5 levels available:	
Stronger: press this button to increase the strength of backrest massage	Upper IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
Weaker: press this button to decrease the strength of backrest massage.	Upper IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII

### Music

Music	Music on and off	•	3
	Previous	K	3
	Next	P3	3
	Volume up	<b>•</b>	3
	Volume down	•	3º

### 4. Shut off power and finish massage

Press red power button during massage to stop all massage functions immediately, the backrest and footrest will return to original position automatically.

After rated working time, all massage functions will be finished but backrest and footrest won't return to original position.

Switch power off


Figure (switch power off)



- 5. How to download mp3 music:
- 1. Turn off the power of massage chair.
- 2.Pull out the u-disk from the MP3 player.
- Insert the u-disk into USB port of PC (Windows Xp., Windows 2000, WindowsNT.)
- 4.Download your favorite MP3 format music into U-disk .if fails , please firstly format the disk.
- 5. Delete the USB Mass Storage Device on the PC after complete download.
- 6.Pull out the U-disk from PC
- 7.Insert U-disk to the USB port of MP3 player
- 8.Now MP3 music was renewed . you may turn on the power of massage chair .


### Note:

- 1.If fails to play MP3 music, please firstly format the U-disk on PC before Download. Then follow the instruction to insert the U-disk into USB port of Mp3 player.
- 2. Except the U-disk, do not remove or loose the MP3 player.




# Method of usage

- 6. Amrest installation and notice.
- 1). Check if the inner supporting gear are well fixed onto related seat frame position. (figure 1)
- 2). Pull the zip on the lower edge of the armrest.
- 3). Open the big and small cover outside the armrest(shown as figure 2)
- 4). Lift the amrest and ready to install on the chair, pull air-pipe and valve from the seat frame and cross them through relative hole on the armrest side. (figure 3)
- 5). Push the sliding sets in the front part of armrest into the inner supporting Gear. (figure 4)
- 6). Push the end of the armrestinto the revolving shaft. (figure 5)



- 7). Gently hold the armrest side. When revolve the shaft, firstly put into cage ring, then put into big washer and wrest the locknut by specialized tools. (Figure 6).
- 8). Thread the socket head cap screws into upper tightening cap (Figure 7), then use the provided wrench to screw in upper supporting gear and wrest screw tight.
- Thread the socket head capscrews into lower tightening cap (Figure 7), then use the provided wrench to screw in lower supporting gear and wrest screw tight.









Figure7

- 10). Respectively connect air pipe and valve connector with relavent connectors on theiron plate of armrest (Figure 8).
- 11). Check if the armrest is well fixed. If there isn't much swing, close the big and small cover outside the armrest. (Figure 9).
- 12). Close the zipper of lower armrest and finish installation.



14

# Method of usage




Figure9

Be careful don't put stress on the two sides of armrest in order to support the body (Figure 10)



Figure 10

Thread head padair pipe and detection lines into pocket (Figure 12)



Figure12

Be careful don't put stress inwardly on upper arm airbag support board (Figure 11)




Figure11

Respectively connect the backrest trachea according to the number (Figure 13)





Figure13

### 7.FLOOR PROTECTION


Put the heavy massage chairs on the wood floor for a long time may damage the floor, so please place a carpet or other object to avoid this damage.

Caution: Do not move the chairs with its wheels on wood floor, rough ground or in a narrow space. Two people are required to lift the chair.



### 8.METHOD OF MOVEMENT

Make sure that all wires are far above the ground, tilt the backrest backward to a certain degree (with the gravity center resting on the wheels), push the chair forward or backward with your hands and finally resume the chair to the normal position in a slow and gentle manner.



16

# Product specification

Model: A33

Description: Full Body Air-massage Chair
Rated Voltage: 110-120V~ 60Hz 

220-240V~ 50Hz/60Hz

Rated PowerInput: 280W Rated WorkingTime: 15Minutes

Safety Design: Class I

Material introduction: PVC, PA, steel parts and electric &ele -ctron parts

MATERIAL	PU	LEATHER	CLOTH	WOOD